

Aerosol

HIGH SHEAR RESILIENT ADHESIVE

HydraStix products are a next generation line of flooring products for the most demanding of installations.

HydraStix 95 Aerosol is a solvent-free aerosol adhesive recommended for difficult installations of commercial vinyl flooring, VCT and rubber flooring where there is heavy traffic or rolling loads. **HydraStix 95 Aerosol** demonstrates a very aggressive grab and exceptional shear bond strength over other aerosol adhesives, and has tremendous moisture and plasticizer resistance. It can be used in occupied buildings and greatly reduces the handling and application requirements associated with conventional adhesives. **HydraStix 95 Aerosol** is FloorScore® Certified by SCS Global Services for Indoor Air Quality and CRI™ GLP approved.

CONCRETE SUBSTRATE CONDITIONS

On or above grade bare concrete substrates with up to 95% in-situ RH (per ASTM F2170), and a pH of 8.0-11.0 when installing vinyl flooring, LVT, LVP and VCT. 90% in-situ RH and 8.0-10.0 pH when installing rubber flooring.

USE WITH

Vinyl sheet flooring
Vinyl composition tile (VCT)
Luxury Vinyl Tiles and Planks
Rubber flooring

CERTIFICATIONS

- VOC content is below that established by California SCAQMD Rule 1168
- California Section 01350 compliant
- FloorScore® Certified
- CRI™ Green Label Plus approved
- CARB VOC Category: Aerosol Mist Adhesive
CARB VOC Limit is 30%, this product contains zero (calculated) VOCs

LIMITATIONS

- Not for below grade installations
- Shelf life 1 year from date of manufacture, in unopened container. Store indoors at a temperature between 65-95°F.
- Cannot be used over substrates which have been chemically cleaned
- **Do not allow product to freeze**
- Not for use with PVC backed carpet tile or felt-backed sheet goods

BEFORE YOU BEGIN:

Important: Proper substrate preparation is essential. Moisture testing must be performed and documented before installation begins. **Read XL Brands Technical Bulletin titled Substrate Preparation for Adhesives before beginning installation.** This document may be found at www.xlbrands.com/resources/technical-bulletins/substrate-preparations-for-adhesives. If you have questions, contact XL Brands Technical Department at 706-508-5907 Mon-Fri, 8:00am - 5:00pm EST before you begin.

USAGE:

A CLEAN SUBSTRATE IS ESSENTIAL! Thoroughly sweep and vacuum the substrate first. Damp mop to remove any remaining dust or debris. Extra attention to substrate preparation is essential for a successful installation. Due to the many additives being used in or on concrete slabs, it is critical that a bond test be performed. Some treatments will repel any sealer or adhesive. If usage instructions are not completely followed, DO NOT USE THIS PRODUCT.

APPLICATION:

Shake can well before each use. Point can downwards, press the side of the nozzle tip as you slowly walk back and forth overlapping the spray pattern for an even spray coverage. Do not use a sweeping motion as this may create uneven coverage. Clean up drips. Be sure to achieve full coverage. When using on a non-porous substrate, a lighter application may be necessary. A heavier coat may be required on all seams depending on floor coverings installed.

NOTE: It is up to the end user to determine the coverage that is appropriate for flooring and jobsite conditions. Bond testing prior to the installation will help identify the appropriate application rate, open and working time, and any potential bonding problems to the substrate or flooring. To determine the accurate coverage rate, measure and chalk line the substrate into grids (using the appropriate square feet of area for the adhesive application) and spray the entire can of adhesive onto each measured grid area.

FLOORING INSTALLATION:

Roll the floor immediately after the installation is complete with the appropriate roller specified for the flooring type. Sheet flooring seams may be heat welded immediately after installation. Normal traffic may be allowed as soon as the installation, finishing and clean-up are complete. Wait 24-hours for heavy traffic or rolling loads.

OPEN TIME:

Allow the adhesive to dry completely with no transfer to fingers when lightly touched. Open time will vary depending on the adhesive coverage, substrate porosity and the ambient conditions. Working time for the adhesive should not exceed 2 hours.

TRAFFIC:

Follow the flooring manufacturer's installation guidelines; otherwise immediate occupation and use is permitted in dried adhesive installations. Allow at least five days following the installation before conducting wet cleaning procedures or initial maintenance.

SAFETY AND CLEAN UP:

Wet adhesive overspray or drips should be cleaned with soap and water on a clean cloth. Dried adhesive may require the use of a solvent adhesive cleaner. Between uses, clean the spray tip immediately with a clean wet cloth to prevent accumulation of dried adhesive. Empty aluminum spray cans should be relieved of excess pressure and recycled or disposed of in accordance with local requirements. Do not expose to temperatures exceeding 122° F. Prolonged exposure to heat or direct sun may cause container to burst.

DISCLAIMER:

Users should determine the suitability of this information or product for their own particular purpose or application. Do not misuse by deliberately concentrating and inhaling the contents. Manufacturer is not responsible for the misuse of this product. This Technical Data sheet and the information conveyed herein supersede all previous versions. XL Brands, MicroSept, HydraStix and Stix are registered trademarks of Bostik, Inc.. FloorScore is a registered trademark of The Resilient Floor Covering Institute. CRI is a registered trademark of The Carpet and Rug Institute.

COVERAGE:

Rate of application depends on flooring product being installed and porosity of the substrate:

- 80 - 100 square feet per can (approximate): Rubber flooring
- 140 - 150 square feet per can (approximate): Luxury Vinyl Tiles, Planks and Sheet
- 160 - 185 square feet per can (approximate): VCT